

Table of Contents

Introduction and Definitions.....	2
Start-Up Procedures.....	3
a. Pre-Start-Up Procedures.....	3
b. Start-Up and VFD Parameter Checks.....	5
c. Start-Up and Controller Checks.....	6
Sequence of Operation.....	7
Post Start-Up Checks, Seals and Rotation.....	9
Purge Adjustment.....	10
Maintenance and Cleaning.....	11
Troubleshooting.....	12
Belts and Fasteners.....	13
Appendix A.....	17

Field Startup Check list. Return to Thermotech to activate Warranty.

U.S. Patent # 6,4222,299
Canadian Patent # 2,373,417
© 2019 Thermotech Enterprises All rights reserved.

The information in this technical manual is for informational purposes only, and is subject to change without notice. No part of this technical manual may be reproduced without the express written permission of Thermotech Enterprises

Thermowheel and TE logo are registered trademarks of Thermotech Enterprises.

Introduction and Definitions

This manual is intended as a guide to the proper operation and maintenance of Thermowheel® T Series assembled energy recovery units. Please read these instructions prior to operating the equipment. These units are intended to be used in air handler units.

Thermowheels® are designed to operate effectively for a minimum of 25 years. By following these instructions carefully you will attain the same high level of reliability. Thermotech Enterprises is not responsible for units that are damaged by improper operation or maintenance.

Definitions:



Danger Symbol - This indicates procedures that if not followed correctly could lead to serious injury or death



Warning Symbol - This indicates procedures that if not followed correctly could result in severe damage to the unit and potentially void the warranty.

Bearing - 2 or 4 bolt pillow block tapered roller bearing supports the load of the rotor.

Casing - The steel or aluminum structure and optional sheet metal panels that enclose the rotor.

Hub - The central connection point for the spokes. The hub's shaft ride in the bearings.

Media - The corrugated aluminum or stainless steel substrate that provides for the heat and or moisture transfer.

Motor Mount - The hinged steel plate that positions the motor and maintains belt tension.

Motor Sheave - The sheave that the belts ride in.

Purge - The purge is an angled radial seal that uses a small amount of outside air to flush the media.

Quarter Panel - The sheet metal panels that direct the airflow through the wheel.

Rem/loc button - A control on the VFD that puts the drive in remote or local control.

Rim - The outer aluminum metal encasing the media.

Rotor - The rotating portion of the heat recovery wheel.

Seals - The combination rubber and aluminum sections that seal the airstreams.


Spokes - The radial supports connecting the hub to the rim.

Speed Reducer - The speed reducer bolts to the motor and turns down the motor RPM.

TE - Thermotech Enterprises

Start-up Procedures

Pre-Start-Up Checks:

 Prior to start-up, check that all foreign objects, debris and tools are removed from the AHU and the fans are off. Thermotech is not responsible for damage to the wheel or other components if the start-up procedure is not followed.

Factory Service Start-Up Procedure for T Series Energy Recovery Wheels

There is a startup checklist that must be followed and each item completed to ensure proper wheel operation. Please refer to the checklist and once completed return the check list to Thermotech Enterprises. The checklist is provided as a pdf. If you do not have a checklist contact TE and one will be provided.

Rotor:

1. Remove the belts from the motor sheave and rotate the wheel a minimum of one full revolution. The seals are non-contact. If the wheel does not rotate freely it may be due to the wheel being in contact with the seal. If seal drag is noted refer to the seal adjustment procedure on page 8. If the wheel cannot be turned by hand contact TE.

Note: For TC sizes 14-82. To remove the belt an idler pulley will need to be loosened.



Belt being removed from the motor sheave.

Rotate wheel by applying pressure to the rim not the media.

Care should be taken not to damage the media face.




TC-14-82 Idler Pulley

2. The side seals should also be checked for clearance to insure nothing has moved in shipping. If the wheel is in contact with the aluminum encasing the side seals, the wheel will need to be re-centered in the casing. This is done by loosening the bearing bolts and by using the bearing adjusting bolts. Re-center the wheel insuring proper side seal clearance. Re-tighten bearing bolts as follows: 3/8 inch = 35 ft lbs., 1/2 inch = 45 ft. lbs., 3/4 inch = 100 ft lbs. Then re-check the seals for proper adjustment per page 8.

3. Check to ensure sheave/bushing is not rubbing on the gear box.

4. At this point the wheel should rotate freely with no drag or rubbing, with the exception the of rivets at the hub cover. A slight rub here is acceptable.



Side seal on aluminum mount.

Purge Angle:

5. If the unit is supplied with an adjustable purge, determine the proper purge angle from the ordering code on the unit nameplate or the specific data for your project. Ensure proper purge angle setting is correct by visual inspection. The minimum purge angle is 1 degree. There are 10 adjustment points in one degree increments. Refer to page 9 and verify that the purge angle adjustment bolt is in the correct adjustment hole.


Initial Lubrication:


6. Grease bearings using Dow Corning Molykote BR2-plus Lithium based high pressure grease. Apply the grease to the fitting while turning wheel until a slight amount of grease is purged. Remove visible grease residue from the bearing. The bearings are filled with grease prior to shipment. This step may be required if the units have been idle on the job site for more than 6 months.
7. Put belts back on pulley.

VFD and Motor pre-checks:

8. If the unit is provided with a VFD, verify the motor is wired for the correct voltage provided by the VFD.

Final Pre-Start-Up Guide:

 During the following procedures the AHU systems fans will be on and the heat wheel drive will be energized. Only qualified personnel with experience in the operation of large rotating machinery should be involved with these procedures.

 Only qualified personnel with experience in the operation of high voltage motors and drives should be involved with these procedures. TE recommends that you become familiar with the operational manual for the Danfoss drive and the Distech controller manual. TE is not responsible for damage caused by improper operation and or programming of these components.

The following procedures contain references to the Danfoss FC-101 and Distech ECLYPSE Manuals. If your system is utilizing a different VFD and or controller, the start-up procedure should be performed by personnel with experience in the systems and components utilized. This guide can then be used as a framework for start-up only. Specific programming and the steps involved may be changed for the system to operate effectively.

Hard copies of the manuals are shipped in the NEMA 4 case provided for certain units utilizing the full control system.

PDF copies of these documents are available at: danfoss.com and distech-controls.com

Start-Up and VFD parameter checks:

The specific parameters for your product are pre-programmed at the factory and are available in appendix A. There should be no reason to change these parameters. The following checks should be made and are for the Danfoss FC-101 drive only. Different drives may require alternative checks and parameters.



The following steps should be performed with the fans on and set to maximum airflow in both airstreams. This will maximize the torque requirement of the motor.

9. After ensuring that no personal injury or damage to the wheel will happen when wheel begins to turn, move the circuit breaker in the control panel to the on position. If 24V is not applied to terminal 27 Hand On mode does not start the motor, connect terminal blocks 12 and 27 to start. At this time the wheel should start in <30 seconds.

10. Press the off button on the VFD until off is displayed. Press the hand button. Reduce the speed by pressing and holding the down arrow till the 2.0 HZ is displayed in the top left of the screen. Wait until the top line lowers to 2.0 HZ

11. Amp draw should not exceed 80% of the motor's Full Load Amperage X Service Factor from the motor name plate. Navigate to parameter 16-14 to read current motor amperage. Increase parameter 4-18 if an amperage alarm is triggered. Maximum value for parameter 4-18 is 375%.

12. Press and hold the up arrow until the HZ shown in the top left reaches maximum (parameters 3-03, 4-14, 4-19, 6-15). The HZ output takes up to 60 seconds to catch up. Wheel speed should now be approximately 20 RPM for enthalpy, 12 RPM for sensible wheels, and 18 RPH for passive wheels.

13. Check amp draw (parameter 16-14) to ensure this does not exceed FLA x SF on motor name plate. Reduce wheel speed down to min. and back to max. At no time should amp draw exceed this value.


14. Press the auto button until it displays auto. The speed of the wheel is now controlled remotely by the controller.

15. A jumper will be installed on the Distech Controller terminal blocks 16 and 17, this jumper should be removed if a remote signal is used for start/stop. Controls contractor shall wire to these terminal blocks to control start/stop of the wheel. Dependent on the specific options selected this remote start stop may be supplied as part of the control panel or be provided and wired by others.



Caution: Always disconnect main power source before working on wheel, as wheel will restart automatically after power loss when power is restored.

Start-Up and Temperature Controller Checks:


 The Distech ECLYPSE controller is pre-programmed at the factory and is set to provide the correct sequence of operation as described on page 7 of this manual. There should be no need to change or modify any of the programming. Thermotech is not responsible for damage or improper operation caused by unauthorized re-programming.

If there is a requirement for programming changes contact TE.

17. Verify sensor wiring UI1=return air, UI2=supply air, UI3=exhaust air, and UI4=outside air are connected to the correct terminals at the Distech controller.

Distech Controller Webpage Screens:

For access to your Distech Controller's web-based interface contact Thermotech for instruction.



Device		Wired IP	Wifi Key
Controller Name	ECY-S1000-C01377	IP Address 192.168.8.137	IP Address 192.168.0.1
BACnet Device Instance	8137	Subnet Mask 255.255.255.0	Subnet Mask 255.255.255.0
Model Name	ECY-S1000 Rev 1.0A	Gateway 192.168.8.1	Mac Address (wlan0) N/A
Firmware Version	1.15.20115.672	Mac Address (eth0) 64:69:4E:C0:13:77	
Vendor Name	Distech Controls, Inc.		
Host Name	ECLYPSE-C01377		
Host Id	ECYS1000-5D3DF7DB-58F3-54DF-8653-1BCA584E83E7		

When logging on to the controller for the first time the first screen you see is the Device Settings, use the tab labeled Network to adjust ethernet and Wi-Fi settings for the controller.

- The far left tabs include manual motor settings, current wheel status (temperature, wheel mode, and wheel speed), adjustable settings (outlined in the controls sequence on page 7), alarms, trends, link to Thermosteact Pro, and link to Thermotech Webpage. Protocol Notification Settings is where you can find additional settings for BACnet integration. User management settings allow you to change your password. For further information contact Thermotech for detailed guide.

18. If a Rotation Sensor is part of the project, run the wheel for a minimum of 5 minutes at maximum and minimum RPM and verify that the controller is reading the correct RPM, and that the system does not go into alarm. It should be noted that an alarm condition will exist if the wheel stopped for more than 5 minutes or if any of the temperature sensors are disconnected or not properly connected.

Sequence of Operation

The controller receives temperature inputs from four air streams:

Outside Air = Outside air entering the wheel

Supply Air = Supply air, conditioned outside air leaving the wheel

Return Air = Return air from the conditioned space entering the wheel

Exhaust Air = Exhaust air temperature leaving the wheel

Sensors

Temperature sensors (4) in the Outside Air, Supply Air, Return Air and Exhaust Air

Reed switch rotation sensor (1)

Adjustable Setpoints

- **Outside Air Temperature (°F) Cool Enable** = Outside Air Temperature at which the user would like the cooling mode to be enabled, default = 70°F (adjustable setpoint)
- **Outside Air Temperature (°F) Heat Enable** = Outside Air Temperature at which the user would like the heating mode to be enable, default = 40°F (adjustable setpoint)
- **Maximum Supply Air Temperature (°F) Heating Mode** = Maximum temperature in the supply airstream in heating mode, wheel modulates to stay below this value, default = 55°F (adjustable setpoint)
- **Minimum Supply Air Temperature (°F) Cooling Mode** = Minimum temperature in the supply airstream in cooling mode, wheel will modulate to stay above this value, default = 55° F (adjustable setpoint)
- **Minimum Exhaust Air Temperature (°F) Heating Mode** – The minimum temperature that the exhaust air stream can be in heating mode before frost/condensation occurs. The minimum exhaust temperature will override the maximum heating supply air temperature. The default is 5°F, Thermosteact Pro will provide the recommended value.
- **Sleep Time (minutes)** – Time wheel will be “asleep” (stopped) before it is “awaken” (run) in sleep mode, default = 30 minutes (adjustable setpoint)
- **Sleep Awake (minutes)** – Time wheel will “awaken” (run) after being “asleep” (stopped) in sleep mode, default = 2 minutes (adjustable setpoint)

Sequence of Operation

Cool Mode is enabled when:

- **Outside Air Temperature \geq Outside Air Temperature Cool Enable (default = 70°F, adjustable)**
and
- **Outside Air Temperature $>$ Return Air Temperature**

The control outputs 10VDC to the VFD, resulting in a 20 RPM or 12 RPM rotation (wheel type dependent).

In **Cool Mode**, the wheel will modulate to maintain a **Supply Air Temperature** above the **Minimum Supply Air Temperature Cooling Mode (default = 55°F, adjustable)**. The control outputs 0 to 10VDC to the VFD. If the **Supply Air Temperature** is less than the **Minimum Supply Air Temperature Cooling Mode** the wheel will stop rotating.

Sequence of Operation

Heat Mode is enabled when:

- **Outside Air Temperature \leq Outside Air Temperature Heat Enable (default = 40°F, adjustable)** and
- **Outside Air Temperature $<$ Return Air Temperature**

The control outputs 10VDC to the VFD, resulting in a 20 RPM or 12 RPM rotation (wheel type dependent).

In **Heat Mode**, the wheel will modulate to maintain a **Supply Air Temperature** below the **Maximum Supply Air Temperature Heating Mode (default = 55°F, adjustable)**. The control outputs 0 to 10VDC to the VFD. If the **Supply Air Temperature** is greater than the **Maximum Supply Air Temperature Heating Mode**, the wheel will stop rotating.

A **Minimum Exhaust Air Temperature Heating Mode (default = 5°F, adjustable)** is used to protect the wheel from condensation and/or frost. The controller will modulate (0 to 10VDC signal to VFD) to ensure the Exhaust Airstream does not go below the set point. If the exhaust airstream goes below this setpoint, the wheel will stop rotating. The **Minimum Exhaust Air Temperature Heating Mode** overrides all other setpoints.

Sleep Mode is enabled when:

- **Outside Air Temperature Heat Enable (default = 40°F, adjustable) $<$ Outside Air Temperature $<$ Outside Air Temperature Cool Enable (default = 70°F, adjustable)**
- or
- **Outside Air Temperature \geq Outside Air Temperature Cool Enable (default = 70°F, adjustable)** and
 - **Outside Air Temperature $<$ Return Air Temperature**

In sleep mode the wheel stops rotation. **The wheel cyclically turns on for two minutes (adjustable setpoint) every 30 minutes to test air conditions.** The wheel awakes if the mode changes from Heat to Cool.

Disable – The owner may enable/disable the controls using a dry contact input or by enabling manual motor control and turning the motor to off. This stops wheel rotation completely. The wheel will not cycle on and off.

Alarms are auto resetting. An alarm cannot be reset manually but resets when its trigger is fixed. The alarms' statuses are available on the alarm tab of the web interface for:

Temperature probes – The controller checks the temperatures are within range and if there is a fault with the temperature probes.

Rotation alarm – User has the ability to set a low speed alarm trigger, if the wheel falls below this speed for five minutes and it is not in Sleep or Off mode than this alarm will trigger, default = 2 RPM.

How the alarm functions for different modes:

	Cool and Heat	Sleep	Disabled
Temperature Sensor	Active	Active	Active
Rotation Sensor	Active	Inactive	Inactive

Wheel Rotational Speed – RPM is sensed using a sensor that closes once per revolution. Rotation updates every 30 seconds.

Post Start-Up Checks

Post Start-Up Check List:

A visual inspection of all 4 quadrants of the heat wheel is a good last step. Check that all tools and other equipment are removed.

At this point the Thermowheel ® should be functioning smoothly.

Seal Adjustment Procedure

Seal Adjustment Guide:

The seals are set at the factory and should not require adjustment. If the seals are rubbing on the media face, due to installation or other factors, the seals will need to be adjusted.

First, rotate the wheel one full revolution and determine where the wheel media face is rubbing on the seal. Working on one seal quadrant at a time, loosen the seal Tek screws. Then, move the seal away from the wheel surface until no more rubbing is noticed.



Loosening of Tek screws prior to seal adjustment.

A typical large diameter wheel will have a flatness variation of 1/16" from the high to the low point of the wheel surface. If the seals are adjusted correctly, the seal gap will vary that much as the wheel turns, but it should never be touching the wheel surface.

Wheel Rotation Check:

Use the directions to the right to determine the correct direction of wheel rotation. If the direction is incorrect, follow the instructions to change the motor wiring

WHEEL ROTATIONAL DIRECTION

1) STAND IN AIR DUCT, FACING THE EXPOSED MOTOR

OR


2) ARE YOU STANDING IN THE SUPPLY AIR FLOW DUCT?
"YES" – WHEEL TURNS COUNTER CLOCKWISE (GREEN ARROW)
"NO" – WHEEL TURNS CLOCKWISE (RED ARROW)

E.G.

CHANGING DIRECTION:
POWER DOWN THE SYSTEM. GO TO THE MOTOR DRIVE AND SWITCH AROUND TWO OF THE THREE WIRES THAT CONNECT THE MOTOR TO THE DRIVE.

Purge Adjustment Procedure

Refer to specific project data to determine if the purge angle is preset or needs to be adjusted after install. Contact Thermotech if you need to determine the proper purge angle.


 Note: The wheel motor and systems fans should be off while performing this procedure. Care should be taken while working around the media so no damage is done to the media face.

Purge Adjustment For TF Series Wheels:

The purge angle can be adjusted with each purge setting hole equal to one degree. The bolts that position the purge angle are located on the backside of the purge and are not visible. First loosen bolt 2 and 3. Then remove the bolt 1. The whole purge section is then movable to a new location. Re-install bolt 1 in the new hole location and re-tighten all the bolts.




Purge angle detail showing bolt locations on front side of purge.





Purge angle detail showing bolt locations on back side of purge

Purge Adjustment: TC Series Wheels:

The purge angle can be adjusted with each purge setting hole equal to one degree. Bolt number 1 positions the purge angle and is located on the front side of the purge. Bolt number 2 is the pivot point and is located on the inside of the frame and is not visible. First loosen bolt 2. Then remove bolt 1. The purge wiper section is then movable to a new location. Re-install bolt 1 in the new hole location and re-tighten all the bolts.



Purge angle detail showing bolt locations on front side of purge.



The purge wiper bolt 2 pivot point is slotted so as the purge wiper is adjusted it can be moved so that the outer edge of the seal is always in contact with the main rotor seal.

Maintenance and Cleaning

MAINTENANCE PROCEDURES:

Rotor Bearings:

The main rotor bearings have been sized for an L-10 life of a minimum of 25 years; operating 24 hours per day, 7 days a week. The main reason for a main bearing to fail would be a lack of lubrication or hardening of existing grease in the bearing due to evaporation or by penetration of moisture causing corrosion. The bearings are filled with grease at our factory or at the time of start-up to eliminate a future failure. A small amount of grease should be added every 6 months in order to maintain fresh grease inside the bearing. Any excess purged grease needs to be wiped off to avoid it getting blown on to the wheel surface.

All our bearings are greased with a Dow Corning Molycote BR2 Plus Grease which is available through most bearing distributors or from McMaster-Carr Supply Co.

Drive System:

The motor does not require any maintenance and has permanently lubricated bearings.

The speed reducer is grease lubricated as well and does not require any maintenance.

Life expectancy based on our previous experience is in excess of 10 years.

The drive belt tension does not need any adjustment due to the gravity based mounting base used.

The B-type V-belts are installed with a B-437 belt connector manufactured by FLEXCO.

This connector will eventually wear out and need to be replaced. A typical life span is 5 to 10 years depending on the environmental condition. Spare parts and special tools can be purchased directly from the manufacturer or through a local bearing distributor. The following part numbers apply:

- B-437 Fasteners
- B-43755 Holder
- B-43740 Rocker Pin Tool

An illustrated guide on belt and connector replacement is included in this manual on page 12.

Cleaning:

The wheel media does not require any cleaning under normal operating conditions. The key is to make sure the wheel is always turning in order to utilize the counter flow airstreams and the purge sector to keep the media clean. Over the years there might be some accumulation of dirt on the face of the media, but the inside will remain clean.

The best method to clean is to brush the surface on the air discharge side with the airflow on or by using a vacuum cleaner. If the wheel is severely clogged contact Thermotech.

Troubleshooting

All Thermotech products are tested at the factory and should function normally upon start-up. In the unlikely event of a problem here are some basic troubleshooting steps.

Do not hesitate to contact TE for assistance with any of these issues.


Symptom	Solution
Wheel Does Not Turn	<p>If a Distech controller is provided, depending on the software version, the wheel may be in sleep mode. This is a normal condition for sleep mode.</p> <p>If a remote enable / disable is provided check that it is enabled. If not provided check that a jumper is installed per the wiring diagram.</p> <p>Check circuit breaker.</p> <p>Visual inspection to confirm belts are on the sheave and the rotor.</p> <p>With breaker off, follow steps on page 3 to check that the wheel can rotate by hand. If wheel moves freely, check that the motor and speed reducer can be rotated by hand. If either the wheel or motor will not turn, contact TE.</p> <p>Restore power. Verify proper power to VFD. Verify proper power to motor. and connections. If motor is energized and not turning, contact TE.</p>
Wheel Rotation Direction Incorrect.	Reverse power connections to motor.
Noise	Some minor noise should be expected as the wheel spokes pass the lateral or vertical seals. If there is a constant scraping or intermittent scraping, this could be seals rubbing on the rotor. Refer to page 3 to check free rotation of the rotor. If there are other loud or unexpected sounds or vibrations, contact TEI.
Wheel RPM Incorrect	For variable speed wheels. An enthalpy wheel should operate in a range from 20 to 1/2 RPM. A sensible wheel should operate in a range from 12 rpm to 1/3 RPM. Refer to page 7 and verify that the sequence of operation is correct. Check sensor wiring, controller and VFD connections. If wheel is still at incorrect RPM, contact TE.
Wheel RPM Readout Incorrect	On units with a rotation sensor, if the sensor is not reporting accurate RPM. First determine actual wheel RPM with a stopwatch. Compare this to the readout. The rotation sensor should be within 1/8" of the target to accurately report RPM. If read out is still incorrect, contact TE. The rotation sensor can have a lag time of up to 5 minutes in reporting correct RPM.
Incorrect Temperature Readings	Verify sensor wiring. Verify sensor location. The supply and exhaust sensor location are critical for accurate readings. Refer to the installation manual for correct sensor location.
High air loss.	Check seals, refer to page 8 for seal adjustment procedure. Other causes for high air loss may be due to problems in the AHU.
High pressure drop.	Check wheel face for obstruction and fouling. If the wheel face is clogged, it may be cleaned by brushing the surface with the airflow on or by using a vacuum cleaner.

Illustrated Directions


FOR APPLYING B437 AND C531 ALLIGATOR® V-BELT FASTENERS... TO FASTENER-V-BELTING

(not to be used to repair endless v-belts)

INSTALLATION TOOLS



HOLDER
(Required)
B43755—
For "B" Fasteners
C53155—
For "C" Fasteners




**ROCKER
PIN TOOL**
(Required)
B43740—
For "B" Fasteners
C62540—
For "C" Fasteners



TIGHTENER
(Optional)
B43750—
For "B" Fastener
C53150—
For "C" Fastener
Necessary for fixed Center
Drives (used to pull belt ends
together in grooves of
sheaves).




CUTTER
(Optional)
C62520—
For A, B, BB, C
and D belting



MIN. PULLEY DIA.—4.6"
(use B437)

How to determine belt length when belt number is known



MIN. PULLEY DIA.—9"
(use C531)

"B" SECTION

V-Belt No.	Belt Length	V-Belt No.	Belt Length	V-Belt No.	Belt Length	V-Belt No.	Belt Length
B-35	35 1/4"	B-65	64 3/4"	B-100	99 1/4"	B-162	160 1/4"
B-38	38 1/4"	B-66	65 3/4"	B-103	102"	B-173	171"
B-42	42"	B-68	67 3/4"	B-105	104"	B-180	178"
B-46	46"	B-71	70 3/4"	B-108	107"	B-195	192 3/4"
B-48	48"	B-75	74 1/2"	B-112	111"	B-210	207 1/2"
B-51	51"	B-78	77 1/2"	B-120	119"	B-225	220 3/4"
B-53	53"	B-81	80 1/2"	B-124	123"	B-240	235 1/2"
B-55	55"	B-83	82 1/2"	B-128	126 3/4"	B-255	250 1/4"
B-56	55 3/4"	B-85	84 1/2"	B-133	131 3/4"	B-270	265"
B-60	59 3/4"	B-90	89 3/4"	B-136	134 1/2"	B-285	279 3/4"
B-62	61 3/4"	B-93	92 1/4"	B-144	142 1/2"	B-300	294 1/2"
B-64	63 3/4"	B-97	96 1/4"	B-158	156 3/4"		

"C" SECTION

V-Belt No.	Belt Length	V-Belt No.	Belt Length	V-Belt No.	Belt Length
C-51	51 1/4"	C-136	135"	C-285	279 1/2"
C-60	60"	C-144	142 3/4"	C-300	294 1/4"
C-68	68"	C-158	156 5/8"	C-315	309"
C-75	74 3/4"	C-162	160 1/2"	C-330	324"
C-81	80 3/4"	C-173	171 1/4"	C-345	338 1/2"
C-85	84 3/4"	C-180	178 1/4"	C-360	353 1/2"
C-90	89 1/2"	C-195	193"	C-390	383"
C-96	95 1/2"	C-210	207 3/4"	C-420	412 1/2"
C-105	104 1/2"	C-225	220 1/2"		
C-112	111 1/4"	C-240	235 1/4"		
C-120	119"	C-255	250"		
C-128	127"	C-270	264 3/4"		

SAVE... by ordering complete kits



100 Ft. "B" V-Belt
10—B437 Fasteners
1—B43755 Holder
1—B43740 Rocker
Pin Tool



100 Ft. "C" V-Belt
10—C531 Fasteners
1—C53155 Holder
1—C62540 Rocker
Pin Tool

OTHER TYPES OF FASTENER-V-BELTING AVAILABLE



Double "V"
... for serpentine
type of drive.
BB section only.
(uses BB4 fastener)




"Ruff" Top
for V-Belt
conveyors
A, B, C, D
section

When belt number (length) is not known


1

Set motor using $\frac{1}{3}$ of its take-up



2


Wrap belt around sheaves, pull tight, and mark



3

Correct the length

EXAMPLE:




HOW TO APPLY ALLIGATOR V-BELT FASTENERS

(Caution: Use only Fastener V-Belting)




STRAIGHTEN BELT END.

Reverse-bend end of belt as shown to remove curl




INSERT BELT IN HOLDER.

Press against flat surface to square belt end with end of holder. Tighten holder screw.




INSERT FASTENER IN


HOLDER, tight against end of belt. Be sure belt stays flush with end of holder.




DRIVE NAILS, one at a time, with light hammer blows. Work on a solid surface.



REMOVE BELT from holder.



DRIVE NAILS all the way through fastener into soft wood. (do not crush fastener)




BEND NAILS AND CLINCH.

(do not crush fastener)

REPEAT THESE STEPS TO APPLY OTHER HALF OF FASTENER.

Note: For line shafts or outboard bearings, wrap belt around shaft before applying second half of fastener.




How to remove rocker pin...

(REMOVE ONLY WHEN NECESSARY)


Place screwdriver in slot of rocker pin... make 1/2 turn... push pin out of fastener.

How to insert rocker pin


1 ARRANGE PARTS OF ROCKER PIN TOOL AS SHOWN BELOW:




2 SHOVE PARTS TOGETHER... IN THIS POSITION



3 BRING FASTENER PARTS TOGETHER




4 INSERT ALIGNING PIN INTO FASTENER




Push rocker pin into fastener (don't force)—turn screwdriver while applying slight pressure.

5 LOCK PIN IN PLACE



Use finger to keep rocker pin centered in fastener. Turn pin with screwdriver until you feel a slight click.

6 CHECK TO BE SURE PIN IS LOCKED



Properly locked, pin cannot be pushed through fastener... slots will be in this position.

FLEXIBLE STEEL LACING COMPANY

2525 Wisconsin Avenue, Downers Grove, IL 60515-4200 U.S.A.
Tel: (630) 971-0150 Fax: (630) 971-1180



APPENDIX A

- Warranty Statement
- VFD Programming Changes
- Wiring Diagram
- BACnet Settings and Points Access Guide

TF and TR Series 10 YEAR PARTS & LABOR WARRANTY

TC Series 3 YEAR PARTS & LABOR WARRANTY

This warranty covers the items listed in this manual and starts on the date listed on the cover of this manual.


Warranty Statement:

This warranty includes all* equipment as stated herein, materials, and workmanship associated with the energy recovery wheels and accessories provided and installed by Thermotech. All material is warranted to be free from defects in material and workmanship when used in a proper and normal manner. Should any failure to conform to the above appear within the warranty period, Thermotech Enterprises shall upon prompt notification and confirmation that the product has been stored, installed, started, operated, and maintained properly, and in accordance with the THERMOWHEEL® OWNERS MANUAL and STARTUP CHECKLIST, correct the non-conformity at Thermotech's option, either by repairing any defective part or by providing a repaired or replacement part. Installation labor where applicable, will be provided at no additional cost to the owner.


The completed startup checklist must be returned to Thermotech Enterprises within 30 days of unit on site operation to activate warranty.

* This warranty applies to drive and control components when purchased and assembled by Thermotech. If control components and/or variable frequency drive are provided by others, Thermotech will provide motor manufacturer standard warranty only.

Distech Controller BACnet Settings Guide



After logging onto the controller, click the drop down arrow next to Protocol Notification Settings on the left side of the page. Then click BACnet Settings, page should look like picture above. To access the list of BACnet Object, click Export BACnet Object List towards the bottom of the page.



The routing tab under BACnet settings looks like the picture above. Enable routing of BACnet packets between BACnet MS/TP controllers connected to the ECLYPSE Connected System Controller's RS-485 port and BACnet/IP controllers connected to the ECLYPSE Connected System Controller's Ethernet Switch ports.

Distech Controller BACnet Settings Guide

The screenshot displays the 'Network IP Ports' configuration page. The left-hand navigation menu is expanded to show 'BACnet Settings'. The main panel features a top navigation bar with tabs for 'General', 'Routing', 'Network IP Ports', 'Network MS/TP Ports', and 'Diagnostics'. The 'Network IP Ports' section includes a toggle for 'IP Port 1' (currently off), a 'Network Number' field set to '1', and a 'BACnet IP UDP Port' field set to '47808'. Below these are 'BBMD' and 'Foreign Device' toggles, both set to 'Off'. An 'Apply' button is located at the bottom right of the settings area.

Network IP Ports - This sets the IP network configuration parameters (on-board port) as well as the BACnet Broadcast Management Device (BBMD) and Foreign Device for intranetwork connectivity.

The screenshot displays the 'Network MS/TP Ports' configuration page. The left-hand navigation menu is expanded to show 'BACnet Settings'. The main panel features a top navigation bar with tabs for 'General', 'Routing', 'Network IP Ports', 'Network MS/TP Ports', and 'Diagnostics'. The 'Network MS/TP Ports' section includes a toggle for 'On-Board RS-485 Port' (currently off). Below this are several configuration fields: 'Network Number' (5), 'Baud Rate' (38400), 'Mac Address' (0), 'Max Master' (127), 'Max Info Frames' (20), and 'Priority' (Default). An 'Apply' button is located at the bottom right of the settings area.

Network MS/TP Ports – Controller supports one RS-485 port, default settings are shown above.

For further information visit distech-controls.com.

Thermotech Enterprises
5110 W. Clifton Street
Tampa, FL 33634
Tel (813) 865-4701
www.thermotech-usa.com

